



Huawei Ascend G610 volume buttons and power Replacement

Replacing flat volume keys and power

Written By: Smilzo



INTRODUCTION

Replacing flat volume keys and power

Step 1 — volume and power buttons



- remove back cover

Step 2



- remove battery

Step 3



- with the help of a Phillips screwdriver remove the side nine screws, one is under the sticker must be removed
- Remove the screw 10th, it is shorter in the center next to the Sim card slot

Step 4



- With the help of a thin tool to pry the side anchors and remove the central body

Step 5




- display connector release

Step 6



- Unhook the connector sensor brightness

Step 7




- Unhook touch screen connector

Step 8



- Unhook the connector that joins the two boards

Step 9



- With a thin tool to help us to release the motherboard from the hooks

Step 10




- Remove motherboard

Step 11



- With the help of a source of heat to remove the flat audio button and the Power

Step 12



- Replace with the new component

Per rimontare il dispositivo, segui queste istruzioni in ordine inverso.

This document was last generated on 2017-06-22 01:56:26 PM.